

Panel Print Protection Peel Off Instructions

Step 1.

If you receive your SmartBar with printed panels installed, fold the bar top to see front panel slot from above - pull front panel up through the slot of the bar frame completely. Fold the side door a few degrees to see side panel slot.



Step 2.

While side door is folded, pull the small nibs out from top and bottom of panel slot (they are placed to hold panel securely in door). Then slide the side panel out from the side.



Step 3.

Peel off protective clear layers from the fronts of the front & side panels.

Carefully re-insert panels back into place.

* If you receive just the front panel rolled in the shipping tube, simply unroll the print and remove protective layer.

*In some cases there may be an additional thin plastic layer on the backs to peel off as well.

